SERIAL NUMBER LOCATIONS

AGRICULTURAL TRACTORS

	·
1917-1938	Stamped on right hand side of engine block immediately above the front manifold stand.
1939-1952	Stamped on left hand side of engine block near No. 3 cylinder just below the top of the block.
1953-1954	Stamped on transmission housing on cast boss over starter (vertical surface) left hand.
1955-1956 1957-1981 Thru 1964	Stamped on left hand side of transmission on top of upper implement mounting boss.
1965-1975 1975-Later	Stamped on right hand side of transmission on top of upper implement mounting boss.
1968-1976	VIN plate on inside of tool box cover.
1973-1978	VIN plate on left hand of transmission to rear of starter motor.
1979-Later	VIN plate on left hand side rail near front axle.
1979-Later	VIN plate on left hand side of transmission case just inside of clutch pedal.
1977 & Later	VIN decal on inside of radiator access panel
1979-Later	VIN decal located above right front corner of radiator. Remove right front grille panel for access.
1977-Later	VIN plate located on left hand fender between 2nd and 3rd step from the top
1952-1956	Stamped on left hand side of the wheel housing (transmission) directly above starter motor.
1956-1964	Stamped on engine cylinder block nest to number 1 cylinder on right hand side above push rod cover.
1958-1964	1958-1964 Stamped on transmission housing — clutch housing portion. Left hand side
	1939-1952 1953-1954 1955-1956 1957-1961 Thru 1964 1965-1975 1975-Later 1968-1976 1973-1978 1979-Later 1979-Later 1979-Later 1977-Later 1979-Later

VIN - Vehicle Identification Number